

### **Configuring Genetec Security Center**

Last Modified on 11/21/2022 3:59 pm EST

Tested with Genetec Security Center 5.10.0.0 with Device Pack 10.6.0 Tested with SightLogix Firmware 16.0.42

### **Important Notes**

- Please consult the Genetec manuals for detailed operation procedures for SecurityCenter and the Security Desk application.
- The Device Pack 10.6.0 adds a feature that allows Genetec to use only one (1) license per SightSensor, which is especially helpful for dual-imager SightSensors HDs and TCs.
- To add the SightLogix SightTracker PTZ, scroll to the end of this document.

#### Adding Devices to Genetec with Genetec Protocol

- Devices must be in Digest mode in WebConfig (as shown) before adding devices using the Genetec Protocol.
- Click "Save" and the camera will reboot.

sightlogix <sup>*</sup> <	WEB SERVER (SL-12033)							
NETWORK								
DEVICE	Administrative Access							
CALIBRATION	Username root							
POLICY								
MPEG / JPEG	Password push2edg Show Password Confirmation							
TRACKER	Hide Login Image							
WEB SERVER								
MAINTENANCE	Authentication							
INFO	Web Authentication Type Digest  Veb Server Mode HTTP and HTTPS  V							
CAMERA NEIGHBORHOOD KITTP 1.1 Pipelined Requests								
ONLINE HELP								
	ONVIF Access							
$\bigcirc$ $\otimes$	Username service							
SAVE REVI	RT Password test1234 Password Confirmation							
Persistent UUID for ONVIF Discovery								

- From the Genetec Config Tool, go to the Video unit viewer and click the appropriate Archiver.
- Select "Video Unit" from the bottom-left menu.
- In the dialog that appears, select "Genetec Protocol" as the Manufacturer.
- Enter the IP address for the camera you are adding.
- Enter the camera username and password (default username is "root", default password is "push2edg")
- Click Add (or Add and Close). The device is added to the tree.



🚯 Config Tool 🖉 📄 Camera conf	🖉 🖉 Area view	■' Video >	System	Archive tran	
📚 Roles and units 📼 Archive transfer	🖻 Modules 🔺 Cloud Storag	ge < > 🛤	🏶 SL-12033		
Search 🕎					
Archiver	Type: Video unit				
▶ 📚 SL-12036 ▶ 📚 SL-12524	lcon: 📚 ▼ Name: SL-12033				
▶ 🏶 SL-13294 ▶ 🟶 SL-14199	Description:				
ア Media Gateway 茾 Media Router	Logical ID:				
😱 Unit Assistant	Relationships:	Manual add Manufacturer Product type		•	
	+ ×	IP address HTTP port Authentication	80 🗘 📀	38 🗢 Hostname II	2v6
	Manufacturer: 🗢 Sightl. Product type: SightSen: MAC address: 00-18-08-	Username Password			
	Firmware version: 16.0.42	Use HTTPS	OFF		
	Audio: <b>No</b> SSL: <b>No</b>	Location	SHARE-PC-8		
		Add		Close Add and c	lose
	it ancollmont 💼 Unit -	Conv confirment	on tool 🔥 Maintena		
+ Video unit → × Delete ∦ Ur	SSL: No		(		tose

#### **Creating Continuous, Scheduled, or Alarm-based Recordings**


Once you've added cameras, create and configure alarms as follows:

- Expand the unit in the sidebar, select the camera feed you want to record (there will be two feeds for SightSensor HDs and TCs) and then select the Recording tab.
- Under Recording settings select "Custom settings".
- Under Recording modes select "Continuous".
- If the device is a dual-imager mode, Repeat the above steps for device on Camera 02. Note that motion is only reported on Camera 01 (the 1080p Visible stream). The Thermal (Camera 02) stream should be set to record continuously.



✿ Config Tool ■ Camera conf	🛛 🕺 🖏 Area view 👋 🖬 🖓 Video 🛛 X 🔮 System 🛛 X 🎥 Archive tran					
📚 Roles and units 💻 Archive transfer	🔄 Modules 🔹 Cloud Storage 🖌 🔉 🛤 👼 SL-12033 - Camera - 01					
Search		📰 Identity		ording Video analytics	n Color	🌨 Hardware
A SHARE-PC-8		lucitity	Hide Hee	and and and and a second second		marchiarc
Archiver	Recording settings: O Inherit from Archiver					
⊿ 📚 SL-12033	Custom settings					
SL-12033 - Camera - 01						
📼 - SL-12033 - Camera - 02	Recording modes: Continuous Cameras are recording continuously					
▶ 🦈 SL-12036						
▶ 🖤 SL-12524	Automatic cleanup: 🧰 🙆 after 1 💠 days					
▶ 🌚 SL-13294						
▶ 🗣 SL-14199						
P Media Gateway						
🕆 Media Router						
🐝 Unit Assistant						
0						
🕂 Video unit 🔻 🏦 Unit enrollment	📚 Unit 👻 🍺 Copy configuration tool 🛛 🚸 Maintenance 👻					

• Click apply on the bottom right to apply the settings



### **Configure Motion**

- Select the "Video analytics" tab.
- Click the Motion Detection Tab for each camera feed and verify that motion detection is turned on and detection is done on the unit.


Config Tool Rearing Confi								
Search     ✓       ▲ SI-ARE-PC-8     ▲       ▲ SI-12033     Camera - 01       ■ SI-12033 - Camera - 01     ✓       ■ SI-12033 - Camera - 02       ▶ SI-12036       ▶ SI-12036       ▶ SI-12037 - Camera - 02       ▶ SI-12038 - Camera - 02       ▶ SI-12034       ▶ SI-13294       ▶ SI-14199       ▶ Media Gateway       ↑ Media Router       ▶ Unit Assistant	Cking         Detection is done on: Archiver         O Unit           nonitoring         Image: Configure motion detection on unit         Image: Disabiling this setting might cause a unit reconnection.							

#### **Creating Event Action on Motion Detection**

# sightlogix

Once you've added cameras, create and configure alarm action as follows:

- In the camera view, select the camera feed which you would like an action performed on when motion is detected.
- Click "Identity"
- Click "Actions" Under "Relationships", and click
- Select "Motion on" as the triggering event
- Select "Add bookmark" as the action to perform
- Select the appropriate camera to apply the action to
- Enter a description for the bookmark event
- Click Save



### **Using Genetec Security Desk**

Security Desk is another executable that lets you view live video, playback and bookmarks. To use:

- Launch Security Desk and log in
- Click the monitoring tab
- Click on the cameras and drag them to view





### Add SightLogix Devices as an ONVIF Device (Legacy)

- From the Config Tool, go to the Video unit viewer and click the appropriate Archiver.
- Select "Video unit" from the bottom-left menu.
- In the dialog that appears, select ONVIF as the "Manufacturer."
- Enter the IP address for the camera you are adding.
- Enter the ONVIF username and password (default username is "service" and the default password is "test1234").
- Click Add (or Add and Close). The device is added to the tree.

## **sightlogix**

🚯 Config Tool 🖉 🐨 Video	x 🕜 🍖 🛃 🕯 @Admin@share-pc.8) 🔔 Tue 108 PM 📃 🛃 💷
< > 🗱 🗄 Archiver	
Statch         ▼ <ul></ul>	Type: Archiver Kors: S Name: Archiver Logical ID: Relationships: Podduct type AI Podduct type AI Cose Add and dose
0	
🕂 Video unit 🝷 🗙 Delete 👘 Un	it enrollment 🛛 🚸 Maintenance 🕶
🖷 O 🖽 🤮 肩	🖸 🖉 🥹 🖏 🎻 🌍 🔛 😵 🌍 🌣 🔤 🕹 🔨 🖓 🖓

### Adding SightTracker PTZ to Genetec

- Add the SightTracker PTZ using ONVIF as the "Manufacturer" (as shown above)
- Once successfully added, the camera unit will have 2 streams, as shown:


4 😻 192.168.50.192 - Unit
🐨 192.168.50.192 - Camera - 01
🐷 192.168.50.192 - Camera - 02
► CL 12022

- Disable the first stream, as follows (and as shown below):
  - Click on camera object
  - Go to the "Peripherals" tab
  - Click the "Camera 01" line
  - Click on the red circle at the bottom to disable the stream

## sightlogix

Search 💙									1
🔺 😂 SHARE-PC-8 🔶						Identity	Properties	Peripherals	Location
🖌 📑 Archiver									
▶ 🧇 192.168.50.14 - Unit		Name -	0 01	State	Logical ID	Description			
و 😥 192.168.50.24	-	<b>192.168.50.192</b>				_	_		
🕨 🐲 192.168.50.38 - Unit		9 192.108.50.192	- Camera - UZ						
▶ 🍩 192.168.50.106 - Unit									
🛥 🍩 192.168.50.127 - Unit									
🐨 onvif 192.168.50.1 💋 - Camei									
▶ 🐲 192.168.50.140 - Unit									
- 🥥 192.168.50.192 - Unit									
🐨 192.168.50.192 - Camera - 0'									
🐨 192.168.50.192 - Camera - 02									
▶ 🧼 SL-12033									
▶ 🧼 SL-12036									
▶ 📚 SL-12524 50.222									
▶ 📚 SL-12568 50.241									
▶ 🧇 SL-13286									
▶ 🖤 SL-13294									
▶ 🐲 SL-14199									
▶ 🖤 SL-14631									
• 🐢 SL-17163									
🌪 Media Gateway									
<table-cell-rows> Media Router</table-cell-rows>									
🗞 Unit Assistant 👻									
		/							

Click Apply



• The unit object will now have 1 stream, as shown



- All video / alarm events directions will be set up as explained in "Creating Continuous, Scheduled, or Alarmbased Recordings", above.
- You may manually navigate the SightTracker PTZ in the Genetec Security Desk by doing the following:
  - Drag the live video screen to pan and tilt the camera
  - $\circ~$  Use the mouse scroll or the side handle bar to zoom in and out



