Configuring OpenEye

Last Modified on 07/21/2023 4:01 pm EDT

Tested with OpenEye 1.8.0.8271
Tested with SightLogix Firmware 16.2.12 (required for OpenEye integration)

Add SightLogix Devices as an ONVIF Device

- In WebConfig, go to the Camera tab and set VMS Type to ONVIF H.264



- Next, click the Web Server tab and check the box 'Persistent UUID for ONVIF Discovery'.

(c) 2024 SightLogix | 745 Alexander Rd | Princeton NJ | 08540 | +1 609.951.0008



- Click Save.

Set Up OpenEye

Next, in OpenEye:

- Add your SightSensor as an ONVIF device using the default credentials (service/test1234)
- Check the "Use Camera Side Motion Detection" box and click Save.

(c) 2024 SightLogix | 745 Alexander Rd | Princeton NJ | 08540 | +1 609.951.0008



(c) 2024 SightLogix | 745 Alexander Rd | Princeton NJ | 08540 | +1 609.951.0008